

TEQSPORT GR86 TOW HOOK INSTALLATION MANUAL



This Installation Manual is intended for the following models:	
2022+	Toyota GR86

PROLOGUE:

Study these instructions completely before proceeding to assembly. The installer must have a thorough knowledge of automotive systems operation. If unfamiliar with any of the concepts outlined in this instruction, we recommend the installation be completed by a qualified professional.

WARNING!

Extreme caution should be taken when performing maintenance or performance upgrades to your vehicle. Please observe and abide by any Warning or Caution labels placed on the various components and tools used when servicing your vehicle. If you have any questions regarding installation or the various components included with the TEQSPORT GR86 Tow Hook, consult with a Professional Mechanic, or contact TEQSPORT for more information.

PARTS INCLUDED:

Item	Quantity	Description
1	1	Tow Hook
2	1	Tow Strap
3	1	Cutting Template

TOOLS REQUIRED:

- Ratchet
- Ratchet Extension(s)
- Assorted Metric Wrenches
- Assorted Metric Sockets
- 1 1/8" Hole Saw
- Drill

SAFETY REQUIREMENTS:

- Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- Always turn the ignition to the OFF position and disconnect the NEGATIVE battery terminal.
- Always use properly rated jack stands when working under your vehicle.
- Always keep limbs and parts away from moving drivetrain parts.
- Only operate drivetrain in a safe space and well-ventilated areas.

BEFORE YOU BEGIN:

Remove contents from the TEQSPORT GR86 Tow Hook and verify that ALL necessary hardware is present.

PROCEDURE:

1. Place the transmission in Park position (or in Reverse gear if equipped with a manual transmission). Apply the parking brake.
2. Locate the Cutting Template. Position the Template onto the Front Tow Hook Cover as shown. The Template will lock into place within the Grille. *Figure 1.*



Figure 1

3. Using a 1 1/8" Hole Saw, drill through the opening of the Cutting Template and Front Tow Hook Cover. Be careful not to drill too far past the Cover. *Figure 2.*



Figure 2

4. Clean up any burrs from the cut.
5. Locate the Tow Hook. Thread it into the OE Tow Hook Location. Use a socket to tighten the Hook. *Figure 3.*



Figure 3

6. Thread the Tow Strap onto the Tow Hook until the Adapter is as far as it will go with the TEOSport Logo facing up. *Figure 4.*



Figure 4

7. Use one wrench to secure the Tow Strap in place, and a second wrench to tighten the Jam Nut against the Strap. *Figure 5.*



Figure 5

END

Additional Technical Support:
Contact TEQSPORT at info@teqsport.com
Or call 770-832-7184 between 9am and 6pm ET