

# TEQSPORT GR COROLLA TOW HOOK INSTALLATION MANUAL



|  |                   |
|--|-------------------|
| This Installation Manual is intended for the following models: |                   |
| 2023+  | Toyota GR Corolla |

**PROLOGUE:**

Study these instructions completely before proceeding to assembly. The installer must have a thorough knowledge of automotive systems operation. If unfamiliar with any of the concepts outlined in this instruction, we recommend the installation be completed by a qualified professional.

**WARNING!**

Extreme caution should be taken when performing maintenance or performance upgrades to your vehicle. Please observe and abide by any Warning or Caution labels placed on the various components and tools used when servicing your vehicle. If you have any questions regarding installation or the various components included with the TEQSPORT GR Corolla Tow Hook, consult with a Professional Mechanic, or contact TEQSPORT for more information.

## PARTS INCLUDED:

| Item | Quantity | Description      |
|------|----------|------------------|
| 1    | 1        | Hook Mount       |
| 2    | 2        | Tow Strap        |
| 3    | 3        | Cutting Template |

## TOOLS REQUIRED:

- Ratchet
- Ratchet Extension(s)
- Assorted Metric Wrenches
- Assorted Metric Sockets
- Drill
- 1 1/8" Hole Saw

## SAFETY REQUIREMENTS:

- Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- Always turn the ignition to the OFF position and disconnect the NEGATIVE battery terminal.
- Always use properly rated jack stands when working under your vehicle.
- Always keep limbs and parts away from moving drivetrain parts.
- Only operate drivetrain in a safe space and well-ventilated areas.

## BEFORE YOU BEGIN:

Remove contents from the TEQSPORT GR Corolla Tow Hook and verify that ALL necessary hardware is present.

## PROCEDURE:

1. Place the transmission in Park position (or in Reverse gear if equipped with a manual transmission). Apply the parking brake.
2. Locate the Cutting Template. Position the Cutting Template onto the Front Tow Hook Cover on the Driver Side of the vehicle. The Template will lock into place within the Grille. *Figure 1.*



*Figure 1*

3. Using a 1 1/8" Hole Saw, drill through the opening of the Cutting Template and Front Tow Hook Cover. Be careful not to drill too far past the Cover. *Figure 2.*



*Figure 2*

4. Clean up any debris or burrs from the cut.
5. Locate the Hook Mount. Thread it into the OE Tow Hook Position. Use a Socket to tighten the Mount to the vehicle. *Figure 3.*



*Figure 3*

6. Thread the Tow Strap onto the Mount until the Adapter is as far as it will go with the TEQSport Logo facing up. *Figure 4.*



*Figure 4*

7. Use a 14mm Wrench to secure the Tow Strap in place, and a 19mm Wrench to tighten the Jam Nut against the Strap. *Figure 5.*



*Figure 5*

END

Additional Technical Support:  
Contact TEQSPORT at [info@teqsport.com](mailto:info@teqsport.com)  
Or call 770-832-7184 between 9am and 6pm ET