

Z1 NISSAN XTERRA X-CLEAT CARGO TIE-DOWN INSTALLATION MANUAL



This Installation Manual is intended for the following models:	
2005-2015	Nissan Xterra

PROLOGUE:

Study these instructions completely before proceeding to assembly. The installer must have a thorough knowledge of automotive systems operation. If unfamiliar with any of the concepts outlined in this instruction, we recommend the installation be completed by a qualified professional.

WARNING!

Extreme caution should be taken when performing maintenance or performance upgrades to your vehicle. Please observe and abide by any Warning or Caution labels placed on the various components and tools used when servicing your vehicle. If you have any questions regarding installation or the various components included with the Z1 Off-Road Nissan Xterra X-Cleat Cargo Tie-Down, consult with a Professional Mechanic or contact Z1 Off-Road for more information.

PARTS INCLUDED:

Item	Quantity	Description
1	2/4/6	X-Cleat Tie Down
2	2/4/6	M6 x 20 Bolt

TOOLS REQUIRED:

- Ratchet
- Philips Head Screwdriver
- 5mm Allen/Hex Key

SAFETY REQUIREMENTS:

- Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- Always use properly rated jack stands when working under your vehicle.
- Always keep limbs and parts away from moving drivetrain parts.
- Always turn the ignition to the OFF position and disconnect the NEGATIVE battery terminal.
- Only operate drivetrain in safe space and well-ventilated areas.

BEFORE YOU BEGIN:

Remove contents from the Z1 Off-Road Nissan Xterra X-Cleat Cargo Tie-Down and verify that ALL necessary hardware is present.

PROCEDURE:

1. Place the transmission in Park position (or in Reverse gear if equipped with a manual transmission). Apply the parking brake.
2. Open trunk of vehicle.

- Using a Philips head screwdriver, remove the (3) screws securing each OE track to the trunk floor.



- Remove the rails and the rear trim piece.
- Slide the Z1 X-Cleat tie downs into the rails. The outside tie downs should face inwards. The center tie downs can face either direction you prefer.



6. Place the rails back into the floor of the trunk and secure them with a supplied M6 x 20mm bolt through each tie down. Torque bolts to 6-7ft-lbs.



7. Check vehicle for loose tools/items.

Completed installation of the Z1 Off-Road X-Cleat Tie Downs should look as shown below:



END

Additional Technical Support:
Contact Z1 Off-Road at info@z1offroad.com
Or call 678-839-8019 between 9am and 6pm ET