

# Z1 OFFROAD SEAT RISERS INSTALLATION MANUAL



## **PROLOGUE:**

Study these instructions completely before proceeding to assembly. The installer must have a thorough knowledge of automotive systems operation. If unfamiliar with any of the concepts outlined in this instruction, we recommend the installation be completed by a qualified professional.

## **WARNING!**

Extreme caution should be taken when performing maintenance or performance upgrades to your vehicle. Please observe and abide by any Warning or Caution labels placed on the various components and tools used when servicing your vehicle. If you have any questions regarding installation or the various components included with the Z1 Off-Road Seat Risers, consult with a Professional Mechanic, or contact Z1 Off-Road for more information.

## **PARTS INCLUDED:**

Item	Quantity	Description
1	2	Seat Riser
2	2	M10 x 1.25 Socket Head Screw, 30mm
3	4	M6 x 1.0 Button Head Screw, 12mm

## **TOOLS REQUIRED:**

- Hydraulic Jack
- (2) 2-Ton (or greater) Jack Stands
- Ratchet
- Ratchet Extension(s)
- Assorted Metric Sockets
- Assorted Metric Wrenches
- Torque Wrench

## **SAFETY REQUIREMENTS:**

- Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- Always use properly rated jack stands when working under your vehicle.
- Always keep limbs and parts away from moving drivetrain parts.
- Always turn the ignition to the OFF position and disconnect the NEGATIVE battery terminal.
- Only operate drivetrain in safe space and well-ventilated areas.

## **BEFORE YOU BEGIN:**

Remove contents from the Z1 Off-Road Seat Risers and verify that ALL necessary hardware is present.

## **PROCEDURE:**

1. Place the transmission in Park position (or in Reverse gear if equipped with a manual transmission). Apply the parking brake.
2. Adjust the Front Seat to the maximum rearward position.
3. Remove the cover on the (1) one forward mount. *Figure 1.*



*Figure 1*

4. Remove the (2) two bolts securing the front of the seat to the floor. Retain this hardware. *Figure 2.*



*Figure 2*

5. Adjust the seat to the forward position.
6. Remove the Plastic Covers on top of the Rear Seat Bolts. *Figure 3.*



*Figure 3*

7. Remove the (2) two bolts securing the rear of the seat to the floor. Retain this hardware. *Figure 4.*



*Figure 4*

8. Tilt the front of the seat up and position the Seat Risers on the threaded holes on the floor. *Figure 5.*



*Figure 5*

9. Install (1) one M10 x 1.25 Socket Screw into each Seat Riser. Torque to **33 ft-lbs**. *Figure 6.*



*Figure 6*

10. Lower the Front Seat down onto the Seat Risers. Secure the Seat to the Seat Riser using the OE Hardware. Torque to **33 ft-lbs**. *Figure 7.*



*Figure 7*

11. Reinstall the rear Seat Bolts. Torque to **33 ft-lbs**.

12. Reinstall any plastic covers covering the bolts on the seat. *Figure 8.*



*Figure 8*

**END**

**Additional Technical Support:**  
Contact Z1 Off-Road at [info@z1offroad.com](mailto:info@z1offroad.com)  
Or call 678-839-8019 between 9am and 6pm ET