

Z1 SEAT RISER MOLLE PANEL INSTALLATION MANUAL



This Installation Manual is intended for the following models:	
2005-2015	Nissan Xterra (Non PRO-4X)
2005-2021	Nissan Frontier (D40)
2022+	Nissan Frontier (D41)

PROLOGUE:

Study these instructions completely before proceeding to assembly. The installer must have a thorough knowledge of automotive systems operation. If unfamiliar with any of the concepts outlined in this instruction, we recommend the installation be completed by a qualified professional.

WARNING!

Extreme caution should be taken when performing maintenance or performance upgrades to your vehicle. Please observe and abide by any Warning or Caution labels placed on the various components and tools used when servicing your vehicle. If you have any questions regarding installation or the various components included with the Z1 Off-Road Seat Riser MOLLE Panel, consult with a Professional Mechanic, or contact Z1 Off-Road for more information.

PARTS INCLUDED:

Item	Quantity	Description
1	1	MOLLE Panel

TOOLS REQUIRED:

- 5mm Allen/Hex Key

SAFETY REQUIREMENTS:

- Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- Always use properly rated jack stands when working under your vehicle.
- Always keep limbs and parts away from moving drivetrain parts.
- Always turn the ignition to the OFF position and disconnect the NEGATIVE battery terminal.
- Only operate drivetrain in safe space and well-ventilated areas.

BEFORE YOU BEGIN:

Remove contents from the Z1 Off-Road Seat Riser MOLLE Panel and verify that ALL necessary hardware is present.

PROCEDURE:

1. Place the transmission in Park position (or in Reverse gear if equipped with a manual transmission). Apply the parking brake.
2. Install the [Z1 Seat Risers](#) under the Front Seat if you have not done so already.
3. If the (4) four M6 Button Head Screws, 12mm are installed in the Seat Riser, remove them. If they are not installed, locate them. *Figure 1.*



Figure 1

4. Position the MOLLE Panel onto the Seat Risers as shown. Secure with the (4) four M6 Button Head screws removed/located in *Step 4.* Moving the Rear Seat backwards may help with installation. *Figure 2.*



Figure 2

END

Additional Technical Support:
Contact Z1 Off-Road at info@z1offroad.com
Or call 678-839-8019 between 9am and 6pm ET