

Z1 KEYLESS REMOTE ENTRY KEY FOB INSTALLATION MANUAL



PROLOGUE:

Study these instructions completely before proceeding to assembly. The installer must have a thorough knowledge of automotive systems operation. If unfamiliar with any of the concepts outlined in this instruction, we recommend the installation be completed by a qualified professional.

WARNING!

Extreme caution should be taken when performing maintenance or performance upgrades to your vehicle. Please observe and abide by any Warning or Caution labels placed on the various components and tools used when servicing your vehicle. If you have any questions regarding installation or the various components included with the Z1 Motorsports Keyless Remote Entry Key Fob, consult with a Professional Mechanic, or contact Z1 Motorsports for more information.

PARTS INCLUDED:

Item	Quantity	Description
1	1	Key Fob

TOOLS REQUIRED:

- None

SAFETY REQUIREMENTS:

- Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- Always turn the ignition to the OFF position and disconnect the NEGATIVE battery terminal.
- Always use properly rated jack stands when working under your vehicle.
- Always keep limbs and parts away from moving drivetrain parts.
- Only operate drivetrain in safe space and well-ventilated areas.

BEFORE YOU BEGIN:

Remove contents from the Z1 Motorsports Keyless Remote Entry Key Fob and verify that ALL necessary hardware is present.

This product will work with any vehicle that uses a Key Fob as shown above on *Page 1*.

PROCEDURE:

1. Enter the vehicle you desire to connect to.
2. Close the Driver Side Door and lock the vehicle using the “Lock” button on the inside Door Panel.
3. Insert the Key into the ignition and remove it. Repeat this (10) ten times. **This step must be completed within (6) six seconds.** The Hazard Lights on the Gauge Cluster will flash once completed.
4. Once the Hazard Lights have flashed, turn the key to the “ON” position, but do not start the engine.
5. Press and hold the “**LOCK**” button on the new Key Fob until the Hazard Lights flash again. This indicates that the programming is complete.
6. Turn off the vehicle and remove the key. Open the door and test the Key Fob function.

END

Additional Technical Support:

Contact Z1 Motorsports at info@z1motorsports.com

Or call 770-838-7777 between 9am and 6pm ET