

Z1 STEERING WHEEL SPACER INSTALLATION MANUAL

**PROLOGUE:**

Study these instructions completely before proceeding to assembly. The installer must have a thorough knowledge of automotive systems operation. If unfamiliar with any of the concepts outlined in this instruction, we recommend the installation be completed by a qualified professional.

WARNING!

Extreme caution should be taken when performing maintenance or performance upgrades to your vehicle. Please observe and abide by any Warning or Caution labels placed on the various components and tools used when servicing your vehicle. If you have any questions regarding installation or the various components included with the Z1 Motorsports Steering Wheel Spacer, consult with a Professional Mechanic, or contact Z1 Motorsports for more information.

PARTS INCLUDED:

Item	Quantity	Description
1	1	Z1 Universal Steering Wheel Spacer
2	6	M5 x 16mm Screws

TOOLS REQUIRED:

- Ratchet
- Ratchet Extension(s)
- Assorted Metric Wrenches
- Assorted Metric Sockets
- Torque Wrench
- Allen/Hex Keys

SAFETY REQUIREMENTS:

- Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- Always turn the ignition to the OFF position and disconnect the NEGATIVE battery terminal.
- Always use properly rated jack stands when working under your vehicle.
- Always keep limbs and parts away from moving drivetrain parts.
- Only operate drivetrain in safe space and well-ventilated areas.

BEFORE YOU BEGIN:

Remove contents from the Z1 Motorsports Steering Wheel Spacer and verify that ALL necessary hardware is present.

This Spacer is meant for users who already have the Z1 Steering Wheel Hub Adaptor, or another applicable Steering Wheel Hub Adaptor installed. This will **NOT** work with an OE Steering Wheel.

PROCEDURE:

1. Place the transmission in Park position (or in Reverse gear if equipped with a manual transmission). Apply the parking brake.
2. Locate the Z1 Steering Wheel Spacer and the (6) six provided M5 Screws. Position the Steering Wheel Spacer over your Steering Wheel Hub Adaptor, or Steering Wheel Quick Release if applicable, secure with the M5 Screws. *Figure 1.*

NOTE: If you do not already have a Steering Wheel Hub Adaptor or Steering Wheel Quick Release installed, follow the instructions for them here:

- [Steering Wheel Quick Release](#)
- [350Z Steering Wheel Hub Adaptor](#)
- [370Z Steering Wheel Hub Adaptor](#)
- [G35 Steering Wheel Hub Adaptor](#)
- [G37 Steering Wheel Hub Adaptor](#)
- [Q50/Q60 Steering Wheel Hub Adaptor](#)
- [Z Steering Wheel Hub Adaptor](#)
- [Offroad Steering Wheel Hub Adaptor](#)



Figure 1

3. Position the Steering Wheel of your choice over the Z1 Steering Wheel Spacer and secure with the hardware included with the Steering Wheel. The Spacer has (2) two different bolt patterns for different Steering Wheel combinations and can be rotated to fit whatever is necessary.

END

Additional Technical Support:

Contact Z1 Motorsports at info@z1motorsports.com

Or call 770-838-7777 between 9am and 6pm ET