

Z1 TOW STRAP INSTALLATION MANUAL

**PROLOGUE:**

Study these instructions completely before proceeding to assembly. The installer must have a thorough knowledge of automotive systems operation. If unfamiliar with any of the concepts outlined in this instruction, we recommend the installation be completed by a qualified professional.

WARNING!

Extreme caution should be taken when performing maintenance or performance upgrades to your vehicle. Please observe and abide by any Warning or Caution labels placed on the various components and tools used when servicing your vehicle. If you have any questions regarding installation or the various components included with the Z1 Motorsports Tow Strap, consult with a Professional Mechanic or contact Z1 Motorsports for more information.

PARTS INCLUDED:

Item	Quantity	Description
1	1	Tow Strap Eye & Webbing
2	1	Tow Strap Thread Adapter

TOOLS REQUIRED:

- Ratchet
- Ratchet Extension(s)
- Deep Well 17mm
- 17mm Open-ended Wrench
- Plastic Pry Tool

SAFETY REQUIREMENTS:

- Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- Always keep limbs and parts away from moving drivetrain parts.
- Only operate drivetrain in safe space and well-ventilated areas.

BEFORE YOU BEGIN:

Remove contents from the Z1 Motorsports Tow Strap and verify that ALL necessary hardware is present.

PROCEDURE:

1. Place the transmission in Park position (or in Reverse gear if equipped with a manual transmission). Apply the parking brake.
2. Refer to your factory service manual to locate and remove the tow hook cover on the front bumper.
3. Locate the Z1 Tow Strap thread adapter.
4. Thread the larger side into the threads on the front crash bar.
5. Using a ratchet and a deep well 17mm socket, torque down the thread adapter.



6. Thread the nut fully onto the thread adapter.



7. Locate the Z1 Tow Strap eye & webbing.
8. Fully thread the eye onto the thread adapter.
9. Backoff eye the minimum amount until the strap sits parallel to the ground.
10. Using a 17mm open ended wrench, tighten the jam nut against the eye to lock it in place.



11. Inspect vehicle for loose tools/items.

END

Additional Technical Support:

Contact Z1 Motorsports at info@z1motorsports.com

Or call 770-838-7777 between 9am and 6pm ET

Nissan/Infiniti's Recommended Vehicle Recovery Safety Guidelines

- Tow chains or cables must be attached only to the main structural members of the vehicle.
- Pulling devices should be routed so they do not touch any part of the suspension, steering, brake or cooling systems.
- Always pull the cable straight out from the front or rear of the vehicle. Never pull on the vehicle at an angle.
- Stand clear of a stuck vehicle.