

# Z1 D41 DASH PLATFORM 25+ INSTALLATION MANUAL



This Installation Manual is intended for the following models:

2025+

Nissan Frontier (D41)

## PROLOGUE:

Study these instructions completely before proceeding to assembly. The installer must have a thorough knowledge of automotive systems operation. If unfamiliar with any of the concepts outlined in this instruction, we recommend the installation be completed by a qualified professional.

## WARNING!

Extreme caution should be taken when performing maintenance or performance upgrades to your vehicle. Please observe and abide by any Warning or Caution labels placed on the various components and tools used when servicing your vehicle. If you have any questions regarding installation or the various components included with the Z1 Off-Road D41 Dash Platform 25+, consult with a Professional Mechanic, or contact Z1 Off-Road for more information.

## **PARTS INCLUDED:**

Item	Quantity	Description
1	1	Lower Bracket
2	1	Top Plate
3	1	Phone Mount Bracket
4	8	M4 x 0.7 Button Head Screw, 10mm
5	2	Rubber Grommet
6	4	M6 Button Head Screw, 15mm
6	4	M6 x 1.0 Hex Nut
8	4	M6 Washer

## **TOOLS REQUIRED:**

- Trim Removal Tool
- Allen/Hex Keys
- Marker
- Drill
- Drill Bits

## **SAFETY REQUIREMENTS:**

- Always wear safety glasses and any necessary protective garments. If using any fluids, chemicals, or solvents, a respirator is recommended.
- Always use properly rated jack stands when working under your vehicle.
- Always keep limbs and parts away from moving drivetrain parts.
- Always turn the ignition to the OFF position and disconnect the NEGATIVE battery terminal.
- Only operate drivetrain in safe space and well-ventilated areas.

## **BEFORE YOU BEGIN:**

Remove contents from the Z1 Off-Road D41 Dash Platform 25+ and verify that ALL necessary hardware is present.

## **PROCEDURE:**

1. Place the transmission in Park position (or in Reverse gear if equipped with a manual transmission). Apply the parking brake.
2. Using a Trim Removal Tool, pry up and remove the OE Dash Tray. *Figure 1.*



*Figure 1*

3. Remove the Rubber Inlay from the OE Dash Tray.
4. Place the Lower Bracket into the OE Dash Tray as shown below. *Figure 2.*



*Figure 2*

5. Using a marker, mark the (4) four smaller holes of the Lower Bracket and the (1) one Larger Hole onto the OE Dash Tray. *Figure 3.*



*Figure 3*

6. Remove the Lower Bracket from the OE Dash Tray. *Figure 4.*



*Figure 4*

7. Using a 5/16" Drill Bit, drill out the (4) four smaller Marks made in Step 5. *Figure 5.*




*Figure 5*

8. Using a larger Stepped Drill Bit, drill out the Larger Mark made in Step 5. *Figure 6.*



*Figure 6*

9. If you are not running wires through the Dash Platform, install (1) one Rubber Grommet into the Lower Bracket and the Top Plate. *Figure 7.*



*Figure 7*

10. Locate (4) four M6 Button Head Screws, 15mm, (4) four M6 x 1.0 Hex Nuts, and (4) four M6 Washers. Secure the Lower Bracket to the OE Dash Tray with the Hardware, with the Button Head Screws on top, and a Nut and Washer on the Bottom. *Figure 8.*



*Figure 8*

11. Place the Top Plate onto the Lower Bracket. *Figure 9.*



*Figure 9*

12. Locate (4) four M4 x 0.7 Button Head Screws. Install them through the Top Plate and into the Lower Bracket. *Figure 10.*



*Figure 10*

13. Reinstall the Dash Platform Assembly into the vehicle. *Figure 11.*



*Figure 11*

14. Use the remaining M4 x 0.7 Button Head Screws to mount the Phone Mount Bracket, other devices or to be a placeholder in the remaining open holes.

**END**

**Additional Technical Support:**  
Contact Z1 Off-Road at [info@z1offroad.com](mailto:info@z1offroad.com)  
Or call 678-839-8019 between 9am and 6pm ET